



Duct/Immersion

Wall Mount

Hazardous

Room & Duct/Immersion Series

The ACI Hazardous Sensor Series is offered with an explosion proof head, which includes an O-ring, gasket, ground screw, (2) 1/2" NPT female openings, and mounting holes in the base of the housing for ease of installation. The conduit enclosure has a UL Listing of 886 and meets the following: CL. I, DIV. 1 & 2, GR. A, B, C, D; CL. II, DIV. 1, GR. E, F, G; CL.II, DIV. 2, GR. F,G; CL. III; NEMA 3,4, 7ABCD, 9EFG. (Please note: This product should be installed by a trained professional with knowledge of local codes and regulations).

The ACI Hazardous Sensor Series is covered by ACI's Five (5) Year Limited Warranty. The warranty can be found in the front of ACI's Sensors & Transmitters catalog, as well as on ACI's web site, www.workaci.com.



Specifications

Table with 2 columns: Specification Name and Value. Includes rows for Explosion Proof, Dust-Ignition Proof, Raintight, Wet Locations, and various probe lengths.

Ordering

Select one Series (A). If a TT is selected, complete (B), (C), (D), & (E). If a TT version is not selected, only complete (C) & (D). Two piece thermowells are not intended for moving water or high pressure service.

A Sensor Series

- Radio button options for sensor series: A/CP, A/AN, A/CSI, A/3K, A/1.8K, A/20K, A/100-2W, A/1K-2W, A/TT100, A/TT1K, A/TTM100, A/TTM1K.

Ordering options B (Span), C (Configuration), D (Length), and E (Output) with radio button selections.

Build your part number

After completing (A), (B), (C), (D), & (E) from the above table, fill in the Part Number Table below. "Classification" is a factory default.

Part number assembly diagram showing slots for A, B, C, D, E, and Classification (EXPL).

EXAMPLE: A/AN - R - EXPL

